



SERVICE Mounting Instructions

PRODUCT: Tumble Dryer, REFERENCE: Service Support

Montering gummilist på filterhållare
Mounting of rubber seal on the filter holder





For more information contact: Asko Appliances AB, SE 534 82 VARA, Sweden, Phone: +46 (0)512 320 00, E-mail: TechnicalSupport@asko.se

www.asko.com

Art nr: 80 829 47

1/4

SERVICE Mounting Instructions



For more information contact: Asko Appliances AB, SE 534 82 VARA, Sweden, Phone: +46 (0)512 320 00, E-mail: TechnicalSupport@asko.se

www.asko.com

Art nr: 80 829 47

2/4

SERVICE Mounting Instructions

Montering av filterhållare (8079750) i infästning på lucka

Filterhållaren ska vara rumstempererad vid montering. Om filterhållaren förvarats kallt, spola filtret i varmvatten innan montering.

1. Montera först en av de nedre fästpunkterna genom att placera hålet direkt på tappen (se bild 1).
2. Vrid filterhållaren så att den andra nedre fästpunkten ligger mot tappen (se bild 2).
3. Tryck filterhållaren tills fästgaffeln snäppt i läge.
4. Vik upp filterhållaren och tryck med fingrarna ihop låshakarna (se bild 3) samtidigt som filterhållaren skjuts i läge.
5. Montera luddfiltret.




Bild 1




Bild 2




Bild 3

For more information contact: Asko Appliances AB, SE 534 82 VARA, Sweden, Phone: +46 (0)512 320 00, E-mail: TechnicalSupport@asko.se

www.asko.com

Art nr: 80 829 47

3/4

SERVICE Mounting Instructions

Mounting of filter holder (8079750) on the door

The filter holder must be at room temperature at installation. If the filter holder has been cold stored, rinse the filter under hot water before installation.

1. First install one of the lower mounting points by placing the hole directly over the lug (see image 1).
2. Turn the filter holder so that the other lower mounting point is against the lug (see image 2).
3. Push the filter holder until the mounting fork snaps into place.
4. Fold the filter holder up and with your fingers push the catches together (see image 3) at the same time as sliding the filter holder into position.
5. Install the lint filter.




Bild 1




Bild 2




Bild 3

For more information contact: Asko Appliances AB, SE 534 82 VARA, Sweden, Phone: +46 (0)512 320 00, E-mail: TechnicalSupport@asko.se

www.asko.com

Art. number 80 829 47

4/4